

MA NOI NO

CHANNEL LIST 2026

banco behringer x32, 2 stage box (analogiche) 1 cat6 schermato e alimentazione (sala/palco), palchetti per batteria e tastiere, kit microfoni batteria e iem a carico della band e aste a carico della band.

qualora i microfoni non siano quelli indicati, previa comunicazione, si prega di fornire modelli analoghi.

RICHIESTE PER SERVICE:

1 XLR (BASSO)

4 XLR (CHITARRE)

2 DI ATTIVE CHITARRE

2 SM58+XLR (CHITARRA E BASSO)

7 CIABATTE DI CORRENTE

2 MONITOR FISICI (BASSO E VOCE PRINCIPALE (per voce principale in alternativa 2 linkati)

ciabatta xlr analogica "A" posizionata tra batteria e tastiere;

ciabatta xlr analogica "B" posizionata lato chitarra DOVE VERRA' COLLEGATO

L+R+SUB+CORRENTE REGIA;

STAGE IN	MIC/D.I./XLR FORNITO DA	STRUM.	POSIZIONE (FoS)	NOTE	
1	frusta xlr band	cassa	pedana right	1 ciabatta di corrente	A in 1
2	frusta xlr band	rullante up	pedana right		A in 2
3	frusta xlr band	rullante bt	pedana right		A in 3
4	frusta xlr band	hi hat	pedana right	+48	A in 4
5	frusta xlr band	tom 1	pedana right		A in 5
6	frusta xlr band	tom 2	pedana right		A in 6
7	frusta xlr band	tom 3	pedana right		A in 7
8	frusta xlr band	tom 4	pedana right		A in 8
9	frusta xlr band	pan. L	pedana right	+48	A in 9
10	frusta xlr band	pan. R	pedana right	+48	A in 10
11					A in 11
12	xlr service	basso	front right	2 ciabatte di corrente	A in 12
13					A in 13

14					A in 14
15					A in 15
16					A in 16
17	xlr band	piano L	pedana left		A in 17
18	xlr band	piano R	pedana left		A in 18
19	xlr band	key L	pedana left	1 ciabatta di corrente	A in 19
20	xlr band	key R	pedana left		A in 20
21	xlr band	organo L	pedana left		A in 21
22	xlr band	organo R	pedana left		A in 22
23	xlr band	Leslie low	pedana left		A in 23
24	xlr + DI attiva service	Acustica	front left	+48	B in 1
25	xlr service	gtr L (pedaliera)	front left	1 ciabatta di corrente	B in 2
26	xlr service	gtr R (pedaliera)	front left		B in 3
27	xlr + DI attiva service	e. acustica	front left	+48	B in 4
28	xlr+SM58 service	vox bass	front right		B in 5
29	xlr band	vox keys	pedana left		A in 29
30	xlr+SM58 service	vox gtr	front left		B in 6
31	asta dritta + mic band	lead vox	center	1 ciabatta di corrente	A in 31
32	mic band	spare			A in 32
CH STAGE OUT					
1	frusta xlr band	IEM Drum	pedana right		A out 1
2	frusta xlr band	drum 1	pedana right		A out 2
3	frusta xlr band	drum 2	pedana right		A out 3
4	frusta xlr band	drum 3	pedana right		A out 4
5	xlr service	IEM bass	front right		B out 1
6	xlr band	IEM keys	pedana left		A out 5
7	xlr band	IEM L lead	center		A out 6

8	xlr band	IEM R lead	center		A out 7
9	monitor service	wedge lead	center		A out 8
10	xlr service	IEM gtr	front left		B out 2
11	monitor service	wedge bass	front right		B out 3
12		guest		se serve	B out 4
13	xlr service (lato gtr)	front fill		se serve	B out 5
14	xlr service (lato gtr)	P.A. sub			B out 6
15	xlr service (lato gtr)	P.A. top L			B out 7
16	xlr service (lato gtr)	P.A. top R			B out 8

STAGE

