

Sub Stage In	Stage Box In	Desk - In	Mic/D.I.	Fornitura	Instruments	+48	Note Stage	Note FoH
		1	1 Beta52	Service	Kick		Pedana Stage Right	
		2	2 SM57	Service	Snare Top		Pedana Stage Right	
		3	3 SM57	Service	Snare Bot		Pedana Stage Right	
		4	4 e614	Service	Hi Hat	x	Pedana Stage Right	
		5	5 e604	Service	Tom 1 Rack		Pedana Stage Right	
		6	6 e604	Service	Tom 2 Rack		Pedana Stage Right	
		7	7 e604	Service	Tom 3 Floor		Pedana Stage Right	
		8	8 e604	Service	Tom 4 Floor		Pedana Stage Right	
		9	9 e614	Service	Overhead L (SR)	x	Pedana Stage Right	
		10	10 e614	Service	Overhead R (SL)	x	Pedana Stage Right	
		11	11				Pedana Stage Right	
(SD8-Rack Tastiere)		40	12 XLR	Band	Click		Pedana Stage Right	
		13	13 XLR	Service	Bass		Pedana Stage Right	
		14	14 XLR	Service (se serve)	Violino	x	Stage Center	
		15	15 D.I. Attiva	Service (se serve)	Aco Guest	x	Stage Center	
		16	16 SM58	Service (se serve)	Voc Guest		Stage Center	
(SD8-Rack Tastiere)		33	17 XLR	Band	Piano L		Pedana Stage Left (SD8-Rack Tastiere)	
(SD8-Rack Tastiere)		34	18 XLR	Band	Piano R		Pedana Stage Left (SD8-Rack Tastiere)	
(SD8-Rack Tastiere)		35	19 XLR	Band	Keyboard L		Pedana Stage Left (SD8-Rack Tastiere)	
(SD8-Rack Tastiere)		36	20 XLR	Band	Keyboard R		Pedana Stage Left (SD8-Rack Tastiere)	
(SD8-Rack Tastiere)		37	21 XLR	Band	Organo L		Pedana Stage Left (SD8-Rack Tastiere)	
(SD8-Rack Tastiere)		38	22 XLR	Band	Organo R		Pedana Stage Left (SD8-Rack Tastiere)	
		23	23 XLR	Service	Gtr L		Fronte Stage Left	
		24	24 XLR	Service	Gtr R		Fronte Stage Left	
		25	25 D.I. Attiva	Service	Aco	x	Fronte Stage Left	
		26	26 D.I. Attiva	Service	E-Aco	x	Fronte Stage Left	
		27	27					
		28	28 SM58	Service	Voc Dany		Fronte Stage Right	
		39	29 SM58	Service	Voc Forcy		Pedana Stage Left (SD8-Rack Tastiere)	
		40	30 SM58	Service	Voc Perez		Fronte Stage Left	
		41	31 SM58A Wireless	Band	Voc Paolo		Fronte Center	
		42	32 SM58A Wireless	Band	Voc Spare/Guest			
Sub Stage Out	Stage Box Out	Desk - Mix Bus Out	Device	Fornitura	Output	230V AC	Note	
(SD8-Rack Tastiere)		23	1 Personal Monitor XLR	Band	Drum 1		Pedana Stage Right	
(SD8-Rack Tastiere)		24	2 Personal Monitor XLR	Band	Drum 2		Pedana Stage Right	
		3	3 Monitor Wedge	Service	Bass	1 X 5	Fronte Stage Right	
(SD8-Rack Tastiere)		17	4 Personal Monitor I.E.M.	Band	Keyboard	1 X 5	Pedana Stage Left (SD8-Rack Tastiere)	
		5	5 Monitor Wedge	Service	Guitar	1 X 5	Fronte Stage Left	
		6	6 Monitor Wedge x2	Service	Vocals	1 X 5	Fronte Center	
		7	7 Personal Monitor I.E.M.	Band	IEM Paolo L			
		8	8 Personal Monitor I.E.M.	Band	IEM Paolo R			
		25	9 Personal Monitor I.E.M.	Band	IEM Perez			
		26	10 Personal Monitor I.E.M.	Band	IEM Dany			
		27	11 Monitor Wedge	Service (se serve)	Guest 1	1 X 5		
		28	12 Monitor Wedge	Service (se serve)	Guest 2	1 X 5		
Sub Stage Out	Stage Box Out	Desk - Split & Ultratnet Out	Device	Fornitura	Output	230V AC	Note	
(SD8-Rack Tastiere)		21	1 Direct Out Ch1	Band	Kick		Pedana Stage Right	
(SD8-Rack Tastiere)		22	2 Direct Out Ch2	Band	Snare Top		Pedana Stage Right	
Sub Stage Out	Stage Box Out	Desk - Matrix Out	Device	Fornitura	Output		Note	
		11	3 P.A. Sub Up	Service	Sub Up			
		12	4 P.A. Sub Down	Service	Sub Down			
		13	5 P.A. Top Left	Service	Top L			
		14	6 P.A. Top Right	Service	Top R			
Sub Stage Out	Stage Box Out	Desk - Main Out	Device	Fornitura	Output		Note	
		10	M/C	Service	Front			
		15	L	Full Range Left	Main L			
		16	R	Full Range Right	Main R			

Materiale audio al seguito della Band:

F.o.H.	Mixer Midas M32	È richiesta la stesura preventiva a carico del Service residente di un cavo CAT-5e schermato con le estremità terminate Ethercon per la connessione audio Sala Palco				Alimentazione Presa CEE 230V 16A
Stage Rack	Stage Box Behringer S32 Stage Box Behringer SD8 Ricevitori Radio Trasmettitori IEM					Alimentazione Presa CEE 230V 16A